

[illegible]

```

SSSSSSSS DDDDDDDD LL
SSSSSSSS DDDDDDDD LL
SS        DD        DD LL
SS        DD        DD LL
SS        DD        DD LL
SS        DD        DD LL
        SSSSSS DD        LL
        SSSSSS DD        LL
                SS DD        LL
                SS DD        LL
                SS DD        LL
                SS DD        LL
SSSSSSSS DDDDDDDD LLLLLLLLLL
SSSSSSSS DDDDDDDD LLLLLLLLLL

```

TTV

MOD

/★+

15

1/2

1*

1*-

1

end

```
{*****}
{(*)}
{(*) COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
{(*) DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
{(*) ALL RIGHTS RESERVED.
{(*)}
{(*) THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
{(*) ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
{(*) INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
{(*) COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
{(*) OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
{(*) TRANSFERRED.
{(*)}
{(*) THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
{(*) AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
{(*) CORPORATION.
{(*)}
{(*) DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
{(*) SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
{(*)}
{*****}
```

```

Revision history:
V03-002 MIRO370      Michael I. Rosenblum      20-Mar-1984
Define a read state word (TTY$W_RB_RDSTATE) and the
Wrap state bit.

Create TTYDEF.SDL from TTYDEF.MAR. Move macro definitions
to TTYMACS.MAR.

See TTYMACS.MAR for additional history.

```



```
module $TTYVECDEF;
```

```
/*  
/*  
/*  
/*
```

```
aggregate CLASS_DEF structure PREFIX "CLASS";
```

```
    GETNXT      longword unsigned tag '': /*  
    PUTNXT      longword unsigned tag '': /*  
    SETUP_UCB   longword unsigned tag '': /*  
    DS_TRAN     longword unsigned tag '': /*  
    DDT         longword unsigned tag '': /*  
    READERROR   longword unsigned tag '': /*  
    DISCONNECT  longword unsigned tag '': /*  
    FORK        longword unsigned tag '': /*  
    POWERFAIL   longword unsigned tag '': /*  
    TABLES     longword unsigned tag '': /*
```

```
end CLASS_DEF;
```

```
aggregate PORT_DEF structure PREFIX PORT;
```

```
    STARTIO     longword unsigned tag '': /*  
    DISCONNECT  longword unsigned tag '': /*  
    SET_LINE    longword unsigned tag '': /*  
    DS_SET      longword unsigned tag '': /*  
    XON         longword unsigned tag '': /*  
    XOFF        longword unsigned tag '': /*  
    STOP        longword unsigned tag '': /*  
    STOP2       longword unsigned tag '': /*  
    ABORT       longword unsigned tag '': /*  
    RESUME      longword unsigned tag '': /*  
    SET_MODEM   longword unsigned tag '': /*  
    DMA         longword unsigned tag '': /*  
    MAINT       longword unsigned tag '': /*  
    FORKRET     longword unsigned tag '': /*
```

```
    constant 'LENGTH' equals . tag '': /* must be at end.
```

```
end PORT_DEF;
```

```
end_module $TTYVECDEF;
```

```
module $TTYSYMDEF;
```

```
/*  
/*  
/* Miscellaneous symbols used by the terminal driver.  
/*  
/*--  
  
/*  
/* FORK DISPATCHER BIT DEFINITIONS  
/*  
aggregate FORK structure prefix TTY$;  
    FD_UNSol      bitfield mask; /* SEND UNSOLISITED INPUT MESSAGE  
    FD_GETAHD     bitfield mask; /* CREATE A TYPEAHEAD BUFFER  
    FD_DISCONNECT bitfield mask; /* DISCONNECT AND DELIVER HANGUPAST  
    FD_PORTFORK   bitfield mask; /* FORK DISPATCH FOR THE PORT DRIVER  
    FD_UNLINK     bitfield mask; /* UNLINK PUCB & LUCB (DETACH)  
    FD_LINK       bitfield mask; /* LINK PUCB & LUCB (CONNECT)  
    FD_BUSY      bitfield mask; /***** MUST REMAIN AT THE END ****  
end FORK;
```

```
constant (  
    CTRLA, /* 1  
    CTRLB, /* 2  
    CTRLC, /* 3  
    CTRLD, /* 4  
    CTRL E, /* 5  
    CTRL F, /* 6  
    BELL, /* 7  
    BS, /* 8  
    TAB, /* 9  
    LF, /* 10  
    VT, /* 11  
    FF, /* 12  
    CR, /* 13  
    CTRLN, /* 14  
    CTRL O, /* 15  
    CTRL P, /* 16  
    CTRL Q, /* 17 (XON)  
    CTRL R, /* 18  
    CTRL S, /* 19 (XOFF)  
    CTRL T, /* 20  
    CTRL U, /* 21  
    CTRL V, /* 22  
    CTRL W, /* 23  
    CTRL X, /* 24  
    CTRL Y, /* 25  
    CTRL Z, /* 26  
    ESCAPE /* 27  
    ) equals 1 increment 1 prefix TTY$ tag C;
```

```
constant XON equals 17 prefix TTY$ tag C;  
constant XOFF equals 19 prefix TTY$ tag C;  
constant BLANK equals 32 prefix TTY$ tag C;  
constant DOLLAR equals 36 prefix TTY$ tag C;  
constant PLUS equals 43 prefix TTY$ tag C;  
constant ZERO equals 48 prefix TTY$ tag C;
```



```

constant ONE equals 49 prefix TTY$ tag C;
constant SCRIPT equals 96 prefix TTY$ tag C;
constant LOWA equals 97 prefix TTY$ tag C;
constant LOWZ equals 123 prefix TTY$ tag C;
constant LOWESC1 equals 125 prefix TTY$ tag C;
constant LOWESC2 equals 126 prefix TTY$ tag C;
constant DELETE equals 127 prefix TTY$ tag C;
constant NL equals 128 prefix TTY$ tag C;
constant CSI equals 155 prefix TTY$ tag C;

```

```

/*
/* Miscellaneous values
/*

```

```

constant MAXPAGLEN equals 255 prefix TTY$ tag C;
constant MAXPAGWID equals 511 prefix TTY$ tag C;
constant HIGHPL equals 22 prefix TTY$ tag C;

```

```

/*
/* EDIT READ STATES (STORED IN THE MODE FIELD OF THE READ BUFFER)
/*

```

```

constant (
    NORMAL,          /* NORMAL CONTROL-R OR CONTROL-U
    CLRECHO,          /* ECHO WITH TABS EXPANDED TO SPACES
    ECHLINE,          /* ECHO FROM GIVEN STRING
    UPDCURSOR,        /* UPDATE THE CURSOR POSITION THEN EXIT
    EXITING,          /* EXIT NOW
    MOVECURSOR,        /* MOVE THE CURSOR TO ITS FINAL PLACE
    CLRREST,          /* CLEAR THE REST OF THE LINE
    PRMECHO,          /* ECHO OUT A PROMPT
    PRMECHO1,          /* RETURN STATE FOR PROMPT ECHOING
    AESECHO,          /* ECHO AES STRING ALONE
    RVECHO,           /* ECHO READ VERIFY STRING
    SIMCEOL           /* SIMULATE CLEAR TO END OF LINE
) equals 0 increment 1 prefix TTY$ tag K_ER;

```

```

/*
/* EDITING TOKENS
/*

```

```

constant (
    CTRLU,           /* CONTROL-U
    CTRLR,           /* CONTROL-R
    DELEFT,          /* DELETE CHARACTER LEFT
    ESCAPE,          /* ESCAPE PREFIX CHARACTER
    ***** END OF THE NORMAL EDITING CHARACTERRSn
    BACK_CHAR,        /* BACKUP 1 CHARACTER
    FORWARD_CHAR,     /* MOVE FORWARD 1 CHARACTER
    MOVE_EOC,         /* MOVE TO THE END OF LINE
    MOVE_BOL,         /* MOVE TO THE BEGINNING OF THE LINE
    DELETE_WORD,      /* DELETE WORD TO THE LEFT
    QUOTING,          /* AND THE QUOTE CHARACTER
    RECALL,           /* RECALL THE LAST Command
    TOGGL,            /* TOGGL BETWEEN INSERT AND OVERSTRIKE MODES
    UNUSED,           /* *** MUST REMAIN AT THE END ***
    TERMINATE         /* INDICATES CHARACTERS NOT ALLOWED IN EDITING INPUT LINE
) equals 1 increment 1 prefix TTY$ tag K_ET;

```

```

constant EDITNORMAL equals TTY$K_ET_ESCAPE prefix TTY$ tag K;

```

```

/*

```

/* INTERNAL FUNCTION CODES

```
/*
  constant (
    READ,      /* READ FUNCTION
    WRITE,     /* WRITE FUNCTION
    SETM,      /* SET MODE
    SETC,      /* SET CHAR
    HANGUP,    /* HANGUP
    MAINT,     /* MAINTENCE FUNCTION
    CTRL,      /* CONTROL ENABLE
    CONNECT,   /* CONNECT TO DETACHED TERMINAL
    DISCON     /* DISCONNECT FROM ATTACHED TERMINAL
  ) equals 0 increment 1 prefix TTY$ tag C_FC;
```

/* CHARACTER CHARACTERISTICS

```
/*
  aggregate CHAR CHAR structure prefix TTY$:
    CH_FILC    bitfield length 3;
    CH_LOWER   bitfield mask;
    CH_SPEC    bitfield mask;
    CH_CTRL    bitfield mask;
    CH_CTRL3   bitfield mask;
    CH_CTRL2   bitfield mask;
  end CHAR_CHAR;
```

end_module \$TTYSYMDEF;


```
module $TTYRBDEF;
```

```
/*++
```

```
/* Read buffer definitions
```

```
/*
```

```
/* This buffer is allocated everytime a read is issued. The
```

```
/* buffer contains all the information necessary to perform this read.
```

```
/*
```

```
/*--
```

```
aggregate TTYRBDEF structure prefix TTY$;
```

```

RB_TXT          longword unsigned;    /* Address of the first character of
                                        /* the read data.
RB_UVA          longword unsigned;    /* READ BUFFER - USER VIRTUAL ADDR
RB_SIZE         word unsigned;        /* READ BUFFER - BLOCK SIZE
RB_SPARE1       byte unsigned;
RB_ECHLEN       byte unsigned;        /* NUMBER OF CHARACTERS TO ECHO
                                        /* WHEN OUTPUTTING FROM ECHSTR
RB_ECHOAREA     quadword unsigned;    /* WORDS TO ECHO CHARACTERS FROM
RB_ECHSTR       longword unsigned;    /* ADDRESS OF THE FIRST CHARACTER
                                        /* TO OUTPUT DURING EDITECHOING.
RB_PIC          longword unsigned;    /* ADDRESS OF THE PICTURE STRING
                                        /* FOR READ VERIFY
RB_TERM        longword unsigned;    /* THE ADDRESS OF THE TERMINATOR BITMASK
RB_MOD          longword unsigned;    /* MODIFIER LONGWORD
RB_AES          longword unsigned;    /* ADDRESS OF THE AES STRING
RB_AESLEN       word unsigned;        /* THE LENGTH OF THE AESSTRING

RB_RDSTATE_OVERLAY union fill;
  RB_RDSTATE     word unsigned;        /* Read state information word
  RB_RDSTATE_BITS structure fill prefix TTY$;
  RS_WRAP       bitfield mask;        /* THE READ HAS WRAPPED EITHER IN THE PROMPT OR INITIAL STRING
end RB_RDSTATE_BITS;
end RB_RDSTATE_OVERLAY;

RB_LIN          longword unsigned;    /* ADDRESS OF THE FIRST CHARACTER ON
                                        /* THIS LINE.
RB_LINOFF       word unsigned;        /* OFFSET FROM THE BEGINNING OF THE
                                        /* LINE TO THE CURSOR POSITION.
RB_LINREST      word unsigned;        /* NUMBER OF CHARACTERS TO THE RIGHT
                                        /* OF THE CURSOR POSITION, USED BY
                                        /* INPUT EDITING
RB_PRMLEN       word unsigned;        /* LENGTH IN BYTES OF THE PROMPT STRING
RB_TIMOS        word unsigned;        /* READ BUFFER - TIMEOUT SECONDS
RB_CPZCUR       word unsigned;        /* CURRENT CURSOR POSITION
RB_CPZORG       word unsigned;        /* READ BUFFER - ORIGINAL HORIZON
RB_TXTOFF       word unsigned;        /* OFFSET FROM THE BEGINNING OF THE
                                        /* DATA TO THE LOCATION OF THE NEXT CHARACTER
RB_PICLEN       word unsigned;        /* the length of the picture string
RB_TXTSIZ       word unsigned;        /* THE LENGTH OF THE READ.
RB_TXTECH       word unsigned;        /* AMOUNT OF INITIAL STRING TO ECHO
RB_MODE         word unsigned;        /* VALUE INDICATING READ EDIT MODE
RB_RVFLR       byte unsigned;        /* CLEAR CHARACTER FOR READ VERIFY
RB_RVFFIL       byte unsigned;        /* READ VERIFY FILL CHARACTER
RB_ESCTKN       word unsigned;        /* ESCAPE TOKEN CHARACTER
RB_PRM_OVERLAY union fill;
```


TTYDEF.SDL;1

16-SEP-1984 16:46:04.74 Page 7

E 10

```
      RB_PRM
      RB_DATA
    end RB_PRM_OVERLAY;
  end TTYRBDEF;
end_module $TTYRBDEF;
```

address; /* ADDRESS OF BEGINNING OF THE PROMPT
longword unsigned; /* READ BUFFER - DATA

TT

L1

```
module $TTYISDEF;
```

```
/*++
```

```
/* ITEM LIST STACK STRUCTURE
```

```
/*
```

```
/* DESCRIPTION:
```

```
/* THIS STRUCTURE IS ALLOCATED OFF THE STACK WHEN AN ITEM LIST QIO IS
```

```
/* DETECTED.
```

```
/*--
```

```
aggregate TTYISDEF structure prefix TTY$;
```

IS_ACMODE	longword unsigned;	/* ACCESS MODE MAXIMIZED WITH THE MODE OF THE CALLER
IS_EDITMODE	longword unsigned;	/* PLACE TO KEEP THE MODE
IS_BUF	longword unsigned;	/* THE USERS ADDRESS OF HIS BUFFER
IS_BUFLN	longword unsigned;	/* THE LENGTH OF THE USERS BUFFER
IS_INI	longword unsigned;	/* USERS INITIAL STRING ADDRESS
IS_INILEN	longword unsigned;	/* LENGTH OF THE INITIAL STRING
IS_INIBUF	longword unsigned;	/* length of initial buffer for fallback use
IS_ITMLST	longword unsigned;	/* THE USERS ADDRESS OF THE ITEM LIST
		/* USED AS A POINTER TO THE NEXT ENTRY
IS_LASTITM	longword unsigned;	/* USERS ADDRESS OF THE LAST ITEM
		/* CALCULATED FROM BEGINNING ADDRESS AND LENGTH
IS_MODIFY	longword unsigned;	/* THE USERS MODIFIER BITS
IS_PIC	longword unsigned;	/* USERS ADDRESS OF THE PICTURE STRING
IS_PICLEN	longword unsigned;	/* THE LENGTH OF THE PICTURE STRING
IS_PRM	longword unsigned;	/* USERS ADDRESS OF THE PROMPT STRING
IS_PRMLN	longword unsigned;	/* THE LENGTH OF THE PROMPT STRING
IS_PRMBUF	longword unsigned;	/* length of prompt for fallback use
IS_SPECIFIED	longword unsigned;	/* BITMASK OF SPECIFIED ITEM LIST ENTRIES
IS_TERM	longword unsigned;	/* THE ADDRESS OF THE USERS TERMINATOR MASK
IS_TERMLEN	longword unsigned;	/* THE LENGTH OF THE USERS TERMINATOR MASK
IS_AES	longword unsigned;	/* THE ADDRESS OF THE ALTERNATE ECHO STRING
IS_AESLEN	longword unsigned;	/* THE LENGTH OF THE ALTERNATE ECHO STRING
IS_TIMEOUT	longword unsigned;	/* TIMEOUT VALUE
IS_FILLCHR	word unsigned;	/* TWO BYTES SPECIFYING FILL AND CLEAR CHARACTER
IS_INIOFF	word unsigned;	/* OFFSET INTO INITIAL STRING FOR ECHOING

```
constant IS_LENGTH equals . tag K; /* LENGTH
```

```
end TTYISDEF;
```

```
end_module $TTYISDEF;
```

```
module $TTYILDEF;
```

```
/*++
/* Itemlist Descriptor
/*
/* Description:
/* This set of definitions defines the locations of all the fields
/* in the terminal QIO item list.
/*--

    aggregate TTYILDEF structure prefix TTY$:

        IL_LEN      word unsigned;    /* THE LENGTH OF THE BUFFER POINTED TO BY ADR
        IL_TYPE     word unsigned;    /* THE TYPE CODE OF THIS ITEM
        IL_ADR      longword unsigned; /* THE USER SPECIFIED ADDRESS
        IL_RETADR   longword unsigned; /* VALUE RETURNED ADDRESS

        constant IL_LENGTH equals . tag K; /* LENGTH

    end TTYILDEF;
end_module $TTYILDEF;
```



```
module $TTYTADEF;
/*++
/* TYPEAHEAD BUFFER
/*
/* DESCRIPTION:
/* THIS BUFFER IS USED TO STORE CHARACTERS BEFORE PROCESSING AND
/* MOVING THEM INTO THE USERS READ BUFFER.
/* ALLOCATED ON UNSOLICITED DATA OR THE FIRST READ POSTED ON A TERMINAL
/* LINE.
/*--

aggregate TTYTADEF structure prefix TTY$:

    #rcllen = 256;                /* THE LENGTH OF THE RECALL BUFFER

    TA_PUT      longword unsigned; /* PUT POINTER
    TA_GET      longword unsigned; /* GET POINTER
    TA_SIZE     word unsigned;     /* BLOCK SIZE
    TA_TYPE     byte unsigned;     /*
    TA_SPARE1   byte unsigned;
    TA_INAHD    word unsigned;     /* COUNT OF CHARS IN BUFFER
    TA_RCLOFF   word unsigned;     /* NUMBER OF CHARACTERS IN THE RECALL
                                /* BUFFER USED.
    TA_END      longword unsigned; /* END ADDRESS
    TA_RCLSI2   word unsigned;     /* THE SIZE OF THE RECALL STRING
    TA_SPARE2   word unsigned;
    TA_RCL      character length #rcllen tag "A"; /* TYPEAHEAD BUFFER - RECALL BUFFER
    TA_DATA     longword unsigned; /* TYPEAHEAD BUFFER - DATA START

    constant TA_RCLLEN equals #rcllen tag K; /* LENGTH OF RECALL

end TTYTADEF;

end_module $TTYTADEF;
```

```

module $TTYMDMDEF;      /* aka $TTYMODEM via hack in TTYMACS.MAR
/*
/*      Modem control state table definitions
/*
/*
/*      state entry definitions
/*
/*      aggregate MODEM_STATE structure prefix MODEMS;
/*
/*      ST_ONMASK      byte unsigned;      /*output signals to activate
/*      ST_OFFMASK     byte unsigned;      /*output signals to disable
/*      ST_TIMER       word unsigned;      /*timer amount to init
/*      ST_ROUTINE     word unsigned;      /*action routine
/*
/*      constant ST_LENGTH equals . tag C; /* LENGTH
/*
end MODEM_STATE;
/*
/*      transition definitions
/*
/*      aggregate MODEM_TRANS structure prefix MODEMS;
/*
/*      TRAN_TYPE      byte unsigned; /* element type
/*      TRAN_TYPE2     byte unsigned; /* unused element type
/*      TRAN_NSTATE    word unsigned; /* next state offset from root
/*      TRAN_OFFMASK   byte unsigned; /* input signals test on
/*      TRAN_ONMASK    byte unsigned; /* input signals test off
/*
/*      constant TRAN_LENGTH equals . tag C; /* LENGTH
/*
end MODEM_TRANS;
/*
/*      transition type codes
/*
/*      constant (
/*      TRAN_DATASET,      /* dataset
/*      TRAN_TIME,         /* timer
/*      TRAN_END,          /* end of transition list
/*      TRAN_DIALTYPE,     /* test for sysgen parameter
/*      TRAN_DZ11,         /* controller = DZ11
/*      TRAN_NOMODEM      /* line not enabled for modem
/*      ) equals 0 increment 1 prefix MODEM tag $C;
/*
/*      argument type codes
/*
/*      constant (
/*      INIT,              /* init line
/*      SHUTDOWN,          /* hangup command
/*      NULL,              /* null, for detecting preset conditions
/*      DATASET,           /* dataset interrupt
/*      TIMER,             /* timer expiration
/*      ) equals 0 increment 1 prefix MODEM tag $C;
/*
/*      aggregate MODEM_BITS structure prefix TIMCTRLS;
/*      CANCEL            bitfield mask; /*CANCEL TIMER REQUEST

```

```
      ACTIVE      bitfield mask;      /*TIMER CURRENTLY ACTIVE
end MODEM_BITS;
      constant ENABLE equals %X8000 prefix MODEMS tag 'M'; /*mask enable
end_module $TTYMDMDEF;
```



```
module $TTYDEF;
```

```
/*++
```

```
/*
```

```
/* Terminal driver write packet (TWP)
```

```
/*
```

```
/*--
```

```
    aggregate TTYWBDEF structure prefix TTY$;
```

```
        WB_FLINK      longword unsigned; /*
```

```
        WB_BLINK      longword unsigned; /*
```

```
        WB_SIZE       word unsigned; /*
```

```
        WB_TYPE       byte unsigned; /*
```

```
        WB_FIPL       byte unsigned; /*
```

```
        WB_FPC        longword unsigned; /*
```

```
        WB_FR3        longword unsigned; /*
```

```
        WB_FR4        longword unsigned; /*
```

```
        WB_MAP        longword unsigned; /*
```

```
        WB_NEXT       longword unsigned; /*
```

```
        WB_END        longword unsigned; /*
```

```
        WB_IRP        longword unsigned; /*
```

```
        WB_STATUS     word unsigned; /*
```

```
        WB_BCNT       word unsigned; /*
```

```
        WB_RETADDR    longword unsigned; /*
```

```
        constant WB_LENGTH equals . tag K; /* LENGTH
```

```
        constant WB_LENGTH equals . tag C; /* LENGTH
```

```
        WB_DATA       longword unsigned; /*
```

```
    end TTYWBDEF;
```

```
end_module $TTYDEF;
```


0402 AH-BT13A-SE
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION
CONFIDENTIAL AND PROPRIETARY

